

Phonak Cleaning spray.

The cleaning spray is a cleaning product for the maintenance of hearing aids and earmoulds. It removes earwax responsible for the decrease in sound quality, increases the life of hearing systems and preserves their effectiveness.

The cleaning spray is presented in the form of a plastic bottle filled with 1.01 fl. oz (30 mL) of solution. It is equipped with a valve, a diffuser and a brush. The spray button is equipped with a anti-rotation function, allowing a more comfortable use of the spray.

Using advice

Removal of incrusted wax:

The cerumen can be fixed on the edge of the outlet openings of the hearing aid as well as nozzle or vents:

- Apply a light pressure to wet the bristles of the brush way from the hearing aid.
- Scrub with the brush to dissolve and remove earwax.
- Wipe your hearing aid with a dry cloth.

Cleaning the surface of the hearing aid:

- Spray the solution on a dry, soft cloth.
- Rub the surfaces of the hearing aid with the cloth.
- After cleaning, wipe the hearing aid with a soft dry cloth.

Be careful not to spray directly on the hearing aid. It is recommended to perform a daily cleaning of hearing aids and earmoulds.



Product composition

- Water
- Alcohol
- Caprylyl Glycol
- Ethylhexylglycerin
- Benzalkonium Chloride









